

# SlideRenu®

## Residential Slide Resurfacing Kit

### SURFACE PREPARATION AND APPLICATION INSTRUCTIONS

#### Materials you will need:

- Two 3/8" nap rollers (one for application of primer, one for application of color)
- One foam roller (for application of clear coat)
- One foam brush
- Paint trays
- Quart of lacquer thinner
- Clean rags

#### Materials included in SlideRenu Residential Kit

- One quart SlideDetergent (Degreaser)
  - One quart Calcitrol (Scale Remover)
  - One quart ABC (Adhesion Base Coat) Primer
  - One quart kit of ColorShield UV4 (25.6 ounces of Part A (resin) and 6.4 ounces of part B (cure))
  - One quart ChloroShield UV115 (Chlorine and UV-resistant clear sealer)
  - 100 and 320 grit sandpaper
  - Measuring/mixing cups
  - Paint stirrers
  - Gloves
1. Spray on SlideDetergent ... let sit for 2-3 minutes ... scrub with brush or 3M pad. Rinse off.
  2. Spray on Calcitrol ... let sit for 2-3 minutes ... scrub with brush or 3M pad OR if the scale build-up is extremely heavy, wet-sand with 320-400 grit sandpaper. Be sure to wear gloves and long-sleeved shirt. Rinse off and let dry.
  3. Sand surface with 100 grit sandpaper. Rinse off and let dry.
  4. Apply lacquer thinner to clean rag and wipe surface. Let dry.
  5. Using the supplied measuring cups, mix ABC Primer 1:1. (Mix equal amounts of Part A and Part B.) Do not pour without measuring and only measure out what you will use in 2 hours. Once mixed, the product cannot be stored for future use.

6. Apply ABC Primer with 3/8" nap roller. Let dry overnight.
7. Lightly sand surface with 100 grit sandpaper to remove surface contaminates. Rinse off and let dry.
8. Apply lacquer thinner to clean rag and wipe surface. Let dry.
9. Using the supplied measuring cups, mix ColorShield UV4 4:1. (Mix 4 parts of A to 1 part of B. Example: 4 ounces of A and 1 ounce of B.) Do not pour without measuring and only measure out what you will use in 2 hours. Once mixed, the product cannot be stored for future use.
10. Apply ColorShield UV4 using 3/8" nap roller. Let dry overnight. If two coats are required, apply a second coat to the entire surface within 24 hours (Wipe with lacquer thinner in between coats. No need to sand unless bugs or other contaminates dry onto the surface.)
11. Sand surface with 320 grit sandpaper. Rinse off and let dry.
12. Apply lacquer thinner to clean rag and wipe surface. Let dry.
13. Using the supplied measuring cups, mix ChloroShield UV115 1:1:½ (Mix 1 part of A, 1 part of B, and ½ part C. Example: 2 ounces of A, 2 ounces of B and 1 ounce of C.) Do not pour without measuring and only measure out what you will use in 2 hours. Once mixed, the product cannot be stored for future use. Do not shake to mix – avoid getting air bubbles into the mixture.
14. Apply ChloroShield UV115 using a foam roller. If air bubbles are present, 'back-brush' with a foam brush. Let dry overnight. If two coats are desired, apply second coat within 24 hours (Wipe LIGHTLY with lacquer thinner on a clean rag between coats if bugs or other contaminates dry onto the surface. Too much lacquer thinner may turn the ChloroShield UV115 soft. No need to sand)
15. 72 hours after final coat has been applied, sand any rough areas lightly with 320 grit sandpaper and rinse off.

